

VC-TR61 Firmware Release Note

Release Date	Version	Description	Note
2026/2/26	VYW110	<p>New Feature</p> <ol style="list-style-type: none"> Added a hand raise tracking option on the web interface. When enabled, the camera automatically tracks a person who raises their hand. <p>Improvement</p> <ol style="list-style-type: none"> Improved zoom centering accuracy to ensure stable framing during zoom operations. 	
2025/11/14	VYW108	<p>New Features</p> <ol style="list-style-type: none"> Added a Hybrid Mode that enables the camera to automatically switch between tracking and framing. Added an option to select the image mode between Standard and Brilliant. Added a command to switch the HDMI output source between PTZ and Panoramic images. <p>Bug Fixes</p> <ol style="list-style-type: none"> Fixed an issue where configuration importing would fail if the imported file name contained spaces. Fixed an issue where some computers could not detect the camera's UVC output after reconnecting the USB cable. 	
2025/7/18	VYW107	<p>New features</p> <ol style="list-style-type: none"> HEVC format is now supported in panoramic scene when resolution is set to 2160p. PIP is now supported via USB/HDMI. Dante Ready is now supported. The camera can move to a preset position after the target is lost. The shape of the block area can now be customized. The HDMI output can be switched between the PTZ and the panoramic scene <p>Improvement</p> <ol style="list-style-type: none"> Enhanced overall tracking performance. Improved image performance of the camera. 	<p>Note:</p> <p>When upgrading the firmware from VYW100 to the latest version, please first upgrade to the transition version MED003, and then proceed to your desired</p>

Release Date	Version	Description	Note
			version.
2025/03/17	VYW101	Bug fixes 1. Fixed the bug where, sometimes, when camera triggers the Home preset position, the location might not be accurate. 2. Fixed the bug where, sometimes, the audio on/off option was not functional after a reboot.	
2025/02/04	VYW100	First Version	

Upgrade Guide:

(X) VYW100 -> VYW107 or later version (Not compatible)

(O) VYW100 -> MED003 -> VYW107 (Compatible)

(O) VYW101 -> VYW107 or later versions (Compatible)

(O) VYW107 -> VYW108 or later versions (Compatible)